# INFO SHEET · OUTDOOR FITNESS STATIONS

# NWC606 Combi 4



Norwell Combi-4 combines several training stations into one. Combi-4 makes it possible to train the whole body with focus on strengthening the upper body and abdominals. Combi-4 can be used by up to three people at once.

## **HOW TO USE:**

- Start by holding the handles with extend arms, and press your back/body towards the backrest. Put your leg in a straight position and lower and raise legs. Dip as far down as you can, by bending your arms – still with your knees bent and no ground contact.
- Grab the bar palms facing forward a shoulderwidth apart.
  Keep your shoulders back and your core engaged.
  Move slowly upward until your chin is above the bar, then
  equally slowly downward.
- 3. Step up and down and get warmed up by stepping.

The Norwell App and the ID-bands, including training instructions and QR codes, on each fitness station inspire to exercise and give full instruction of use.










# POSITION AND TRAINING ZONE:

Trainingzone =  $13.8 \text{ m}^2 / 148.5 \text{ ft}^2$ 



# DESIGN FOR ALL

All Norwell fitness stations utilize the users own body weight as resistance, therefore the exercises can be performed without risk of injuries. As a result, Norwell fitness stations are challenging and effective regardless of fitness level.

### SAFE DESIGN

The Norwell Outdoor Fitness stations are tested and approved by TÜV Product Service GMbH according to DIN79000, EN 16630 and AfPS GS 2014:01 PA.

### 10 YEAR WARRANTY

10 years against failure due to material or manufactoring defects and corrosion breakthrough on pipes, foundations and welds. Please contact us for more information about warranty coverage, and for sites within 5 km of saltwater.

### 2 YEAR WARRANTY

2 years against failure due to material or manufactoring defects and corrosion breakthrough on all moving parts, plastic and rubber

